

DIAGRAM #1- the corner cutout is the measurement of the side depth + back- Do this for the batting and fabric

DIAGRAM #2- fold the corners right sides together, stitch at ¼" seam allowance, tapering to a point at the inside corner- similar to sewing a dart