
Season 700

709-2 Ruching with Elastic

Fabric: All the fabrics I use on It's Sew Easy TV come from Vogue Fabrics Patterns and Sewing Supplies: The Angela Wolf Pattern Collection







Shirring with the coverstitch machine is easy!

- Place elastic thread in the lower looper.
- Increase looper tension.
- Decrease needle tension.
- With right side of the fabric facing up, Chainstitch, allowing the fabric to gather.
- Either continue around in circles, end each row and tie off tthreads, or turn fabric back and forth.

Use coupon code ITSSEWEASY10 for 10% off everything at www.AngelaWolfPatterns.com

Refer to my blog for more details on ruching and shirring!

Cheers,

















